

WELCOME TO yourTV

- 1 Connect the Roku to your TV. You will be asked to set up your network connection. After the automatic upgrade a device code will appear on your screen. You will need this code to add the device on the Roku website.

Complete these steps online:

- 2 Use this specific link to access the Roku website and set up your account - <https://my.roku.com/add/YTVPolarRoku>

- 3 Once your online account is set up, click on **link device**.

- 4 Enter the device code shown on your TV screen (from step 1).

- 5 You will see yourTV under add channels, click to add.

Complete these steps on your TV:

- 6 The yourTV app will now appear on the Roku on your TV screen. You may need to scroll down through other apps to find it.

- 7 Click on the yourTV app on your TV and enter your customized account ID: _____ and 4-digit password: _____ - you will have to use arrow keys.

- 8 The yourTV app will now be available to choose every time you turn your Roku on.

Need Help? For picture quality or connection issues: 1.888.700.7652
For Roku device issues: 1.888.600.7658 or roku.com