

SIREN



The siren is connected to the control panel, either through hardwiring or wirelessly. Depending on which sensor the siren is programmed to detect, it will pick up the signal from the smoke detector or the glass break sensor, for example, that triggers it to sound. The siren may be programmed to indicate each of its triggers uniquely, meaning the fire siren would be different from the burglary siren.



POLAR